| Ford_V01.20 BMS Function List（Note:For reference only） | |
|---|---|
| NOTES: | |
| ● This function is supported. | |
| ※ This function may be supported, which depends on the actual condition of the vehicle. | |
| ○ This function is not supported. | |
| ▲ This function is the new feature in this version. | |
| Vehicle | BMS |
| C-MAX | ● |
| Edge | ● |
| Escape / Kuga | ● |
| Escape / Mariner Hybrid | ● |
| Escape / Tribute / Mariner | ● |
| Expedition | ● |
| Explorer | ● |
| F-150 | ● |
| Flex | ● |
| Focus | ● |
| Fusion | ● |
| Kuga / Escape | ● |
| Milan | ● |
| MKC | ● |
| MKS | ● |
| MKT | ● |
| MKX | ● |
| MKZ | ● |
| Mondeo | ● |
| Mustang | ● |
| Navigator | ● |
| Ranger / Mazda B-Series / Troller | ● |
| Taurus | ● |
| Transit Connect | ● |