

LEXUS\_V01.20 BLD Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	Area	BLD
GS350	EUROPE AND OTHER	●
GS250	EUROPE AND OTHER	●
GS300h	EUROPE AND OTHER	●
GS450h	EUROPE AND OTHER	●
GS F	EUROPE AND OTHER	●
NX200	EUROPE AND OTHER	●
NX300h	EUROPE AND OTHER	●
RX450h	EUROPE AND OTHER	●
LFA	EUROPE AND OTHER	●
LX570	EUROPE AND OTHER	●
LS460	EUROPE AND OTHER	●
LS600h	EUROPE AND OTHER	●
LX450d	EUROPE AND OTHER	●
GS300h	JAPAN	●
NX300h	JAPAN	●
GS350	JAPAN	●
GS250	JAPAN	●
GS450h	JAPAN	●
GS F	JAPAN	●
RX400h	JAPAN	●
LFA	JAPAN	●
LX570	JAPAN	●
LS460	JAPAN	●
LS600h	JAPAN	●
NX200t	JAPAN	●