

NISSAN_V01.15 BMS Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	BMS
350Z	●
370Z	●
AD	●
ALMERA	●
ALTIMA	●
ARMADA	●
ATLAS	●
ATLEON	●
AVENIR	●
BASSARA	●
BLUEBIRD	●
CABSTAR	●
CARAVAN	●
CEDRIC	●
CEFIRO	●
CIMA	●
CIVILIAN	●
CREW	●
CUBE	●
cube3	●
Datsun GO	●
DATSUN GO+/GO+ PANCA	●
DATSUN TRACK	●
DUALIS	●
ELGRAND	●
EVALIA	●
FAIRLADY Z	●
FRONTIER	●
FUGA	●
GRAND LIVINA	●
JUKE	●
LAFESTA	●
LANNIA	●
LATIO	●
LAUREL	●
LEAF	●
LEOPARD	●
LIBERTY	●
LIVINA	●
MARCH	●
MAXIMA	●
MICRA	●
MISTRAL	●
MURANO	●
NAVARA	●
NOTE	●

NP300	●
NT500	●
NV	●
NV200	●
NV350	●
PALADIN	●
PARAMEDIC	●
PATHFINDER	●
PATROL	●
PICKUP	●
PRAIRIE	●
PRESAGE	●
PRESEA	●
PRESIDENT	●
PRIMERA	●
PULSAR	●
Pulse	●
QASHQAI	●
QUEST	●
RASHEEN	●
RNESSA	●
ROGUE	●
SAFARI	●
Scala	●
SENTRA	●
SERENA	●
SILVIA	●
SKYLINE	●
STAGEA	●
SUNNY	●
SYLPHY	●
TEANA	●
TERRANO	●
TIIDA	●
TINO	●
TITAN	●
TSURU	●
URVAN	●
Venucia D50	●
Venucia e30	●
Venucia R30	●
Venucia R50	●
Venucia T70	●
Versa	●
WINGROAD	●
X-TRAIL	●
XTERRA	●