

PEUGEOT_V01.10 Daig Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Vehicle	System Name	EcuInfo.	Read Codes	Erase Codes	LiveData
106	Engine Control Moduel	●	●	●	●
106	Additional Heating	●	●	●	●
107	Engine Control Moduel	●	●	●	●
107	Manual Gearbox (MMT)	●	●	●	●
107	ESP (BOSCH 8.0 C1)	●	●	●	●
107	Airbag	●	●	●	●
107	Electric Power Steering	●	●	●	●
107	Coded Anti Start	●	●	●	●
108	Engine Control Moduel	●	●	●	●
108	Gearbox	●	●	●	●
108	ABS/ESP	●	●	●	●
108	Airbag	●	●	●	●
108	Instrument Panel	●	●	●	●
108	Air Conditioning	●	●	●	●
108	Electric Power Steering	●	●	●	●
108	Start/Stop Control	●	●	●	●
108	Engine Immobiliser\Hands Free Starting Access Electric Module	●	●	●	●
108	Multifunction Display	●	●	●	●
206	Engine Control Moduel	●	●	●	●
206	Auto Gearbox	●	●	●	●
206	Active Safety (ABS)	●	●	●	●
206	Airbag	●	●	●	●
206	Instrument Panel	●	●	●	●
206	Built-in System Interface (BSI)	●	●	●	●
206	Air Conditioning	●	●	●	●
206	Diesel Additive Function	●	●	●	●
206	Electric Power Steering	●	●	●	●
206	Steering Wheel Switching Module	●	●	●	●
206	Rain/Brightness Sensor	●	●	●	●
206	Driver School Module	●	●	●	●
206	Display/Telematics	●	●	●	●
206	Service Module	●	●	●	●
206	Multifunction Display	●	●	●	●
206	CD Player	●	●	●	●
206	Alarm	●	●	●	●
206	Radio	●	●	●	●
207	Engine Control Moduel	●	●	●	●
207	Auto Gearbox	●	●	●	●
207	Active Safety (ABS)	●	●	●	●
207	Airbag	●	●	●	●
207	Instrument Panel	●	●	●	●
207	Built-in System Interface (BSI)	●	●	●	●
207	Air Conditioning	●	●	●	●
207	Engine Relay Unit	●	●	●	●
207	Trailer Relay Unit	●	●	●	●
207	Electric Power Steering	●	●	●	●
207	Steering Wheel Switching Module	●	●	●	●
207	Parking Assistance Module	●	●	●	●
207	Rain/Brightness Sensor	●	●	●	●

207	Battery Charge Status Unit	●	●	●	●
207	Service Module	●	●	●	●
207	Hands Free Control Unit	●	●	●	●
207	Display/Telematics	●	●	●	●
207	Not Fastened Warning Light (TNB)	●	●	●	●
207	Multiplexed Additive Adding Pump	●	●	●	●
207	High Frequency Receiver	●	●	●	●
207	Under Inflation Detection	●	●	●	●
207	Driver School Module	●	●	●	●
207	Directional Headlamps	●	●	●	●
207	Stolen Vehicle Location Control Unit	●	●	●	●
207	Folding Roof	●	●	●	●
207	Multifunction Display	●	●	●	●
207	CD Player	●	●	●	●
207	Alarm	●	●	●	●
207	Radio	●	●	●	●
208	Engine Control Moduel	●	●	●	●
208	Auto Gearbox	●	●	●	●
208	Active Safety (ABS)	●	●	●	●
208	Airbag	●	●	●	●
208	Instrument Panel	●	●	●	●
208	Built-in System Interface (BSI)	●	●	●	●
208	Air Conditioning	●	●	●	●
208	Trailer Relay Unit	●	●	●	●
208	Lighting Relay Unit	●	●	●	●
208	Electric Power Steering	●	●	●	●
208	Steering Wheel Switching Module	●	●	●	●
208	Steering Wheel With Fixed Central Control	●	●	●	●
208	Parking Assistance Module	●	●	●	●
208	Multiplexed Additive Adding Pump	●	●	●	●
208	Rain/Brightness Sensor	●	●	●	●
208	Battery Charge Status Unit	●	●	●	●
208	Multiplexed Control Panel	●	●	●	●
208	Driver School Module	●	●	●	●
208	Independent Telematic Unit (BTA)	●	●	●	●
208	Matrix Screen Integral To The Instrument Panel	●	●	●	●
208	Telematic Unit	●	●	●	●
208	Siren	●	●	●	●
208	CD Player	●	●	●	●
208	Alarm	●	●	●	●
208	Audio Amplifier	●	●	●	●
208	Radio	●	●	●	●
208 (Ai91)	Engine Control Moduel	●	●	●	●
208 (Ai91)	Auto Gearbox	●	●	●	●
208 (Ai91)	Active Safety (ABS)	●	●	●	●
208 (Ai91)	Airbag	●	●	●	●
208 (Ai91)	Instrument Panel	●	●	●	●
208 (Ai91)	Built-in System Interface (BSI)	●	●	●	●
208 (Ai91)	Air Conditioning	●	●	●	●
208 (Ai91)	Electric Power Steering	●	●	●	●
208 (Ai91)	Steering Wheel Switching Module	●	●	●	●
208 (Ai91)	Steering Wheel With Fixed Central Control	●	●	●	●
208 (Ai91)	Parking Assistance Module	●	●	●	●
208 (Ai91)	Rain/Brightness Sensor	●	●	●	●
208 (Ai91)	Independent Telematic Unit	●	●	●	●
208 (Ai91)	Multiplexed Control Panel	●	●	●	●
208 (Ai91)	External CD Player	●	●	●	●
208 (Ai91)	Telematic Unit	●	●	●	●

208 (Ai91)	Siren	●	●	●	●
208 (Ai91)	Alarm	●	●	●	●
208 (Ai91)	Radio	●	●	●	●
301	Engine Control Moduel	●	●	●	●
301	Auto Gearbox	●	●	●	●
301	Active Safety (ABS)	●	●	●	●
301	Airbag	●	●	●	●
301	Instrument Panel	●	●	●	●
301	Trailer Relay Unit	●	●	●	●
301	Electric Power Steering	●	●	●	●
301	Multiplexed Additive Adding Pump	●	●	●	●
301	Steering Wheel Switching Module	●	●	●	●
301	Parking Assistance Module	●	●	●	●
301	Multifunction Display	●	●	●	●
301	Siren	●	●	●	●
301	Radio	●	●	●	●
306	Engine Control Moduel	●	●	●	●
306	Auto Gearbox	●	●	●	●
306	ABS (BOSCH 5.3)	●	●	●	●
306	Airbag	●	●	●	●
307	Engine Control Moduel	●	●	●	●
307	Auto Gearbox	●	●	●	●
307	Active Safety (ABS)	●	●	●	●
307	Airbag	●	●	●	●
307	Instrument Panel	●	●	●	●
307	Built-in System Interface (BSI)	●	●	●	●
307	Air Conditioning	●	●	●	●
307	Engine Relay Unit	●	●	●	●
307	Trailer Relay Unit	●	●	●	●
307	Diesel Additive Function	●	●	●	●
307	Electric Power Steering	●	●	●	●
307	Steering Wheel Switching Module	●	●	●	●
307	Parking Assistance Module	●	●	●	●
307	Driver Door module	●	●	●	●
307	Passenger Door Module	●	●	●	●
307	Right Headlamp Beam Level Corrector	●	●	●	●
307	Left Headlamp Beam Level Corrector	●	●	●	●
307	Rain/Brightness Sensor	●	●	●	●
307	Driver School Module	●	●	●	●
307	Hands Free Control Unit	●	●	●	●
307	Multifunction Display	●	●	●	●
307	High Frequency Receiver	●	●	●	●
307	Service Module"	●	●	●	●
307	Under Inflation Detection	●	●	●	●
307	Telematic Unit	●	●	●	●
307	Sunroof	●	●	●	●
307	Folding Roof	●	●	●	●
307	CD Player	●	●	●	●
307	Alarm	●	●	●	●
307	Radio	●	●	●	●
308	Engine Control Moduel	●	●	●	●
308	Auto Gearbox	●	●	●	●
308	Active Safety (ABS)	●	●	●	●
308	Airbag	●	●	●	●
308	Instrument Panel	●	●	●	●
308	Built-in System Interface (BSI)	●	●	●	●
308	Air Conditioning	●	●	●	●
308	Engine Relay Unit	●	●	●	●

308	Trailer Relay Unit	●	●	●	●
308	Electric Power Steering	●	●	●	●
308	Steering Wheel Switching Module	●	●	●	●
308	Parking Assistance Module	●	●	●	●
308	Multiplexed Additive Adding Pump	●	●	●	●
308	Driver Door Module	●	●	●	●
308	Driver Seat Memory Unit	●	●	●	●
308	Passenger Seat Memory Unit	●	●	●	●
308	Directional Headlamps	●	●	●	●
308	Hands Free Control Unit	●	●	●	●
308	Battery Charge Status Unit	●	●	●	●
308	Not Fastened Warning Light (TNB)	●	●	●	●
308	Rain/Brightness Sensor	●	●	●	●
308	Display/Telematics	●	●	●	●
308	Service Module"	●	●	●	●
308	Multifunction Display	●	●	●	●
308	High Frequency Receiver	●	●	●	●
308	Lane Departure Warning System	●	●	●	●
308	Windscreen Wiper	●	●	●	●
308	Matrix Screen Integral To The Instrument Panel	●	●	●	●
308	Moving Panel Deflector	●	●	●	●
308	Under Inflation Detection	●	●	●	●
308	Driver School Module	●	●	●	●
308	Audio Amplifier	●	●	●	●
308	Electropump Assembly	●	●	●	●
308	Sunroof	●	●	●	●
308	Folding Roof	●	●	●	●
308	CD Player	●	●	●	●
308	Radio	●	●	●	●
308	Alarm	●	●	●	●
308 (T9)	Engine Control Moduel	●	●	●	●
308 (T9)	Auto Gearbox	●	●	●	●
308 (T9)	Active Safety (ABS)	●	●	●	●
308 (T9)	Vehicle Distance Assistance	●	●	●	●
308 (T9)	Airbag	●	●	●	●
308 (T9)	Instrument Panel	●	●	●	●
308 (T9)	Air Conditioning	●	●	●	●
308 (T9)	Engine Relay Unit	●	●	●	●
308 (T9)	Trailer Relay Unit	●	●	●	●
308 (T9)	Electric Power Steering	●	●	●	●
308 (T9)	Electric Steering Lock	●	●	●	●
308 (T9)	Steering Wheel Switching Module	●	●	●	●
308 (T9)	Parking Assistance Module	●	●	●	●
308 (T9)	Additional Heating	●	●	●	●
308 (T9)	Driver Door control panel	●	●	●	●
308 (T9)	Driver Seat Memory Unit	●	●	●	●
308 (T9)	Seat Belts Not Fastened LED Unit	●	●	●	●
308 (T9)	Directional Headlamps	●	●	●	●
308 (T9)	Rain/Brightness Sensor	●	●	●	●
308 (T9)	Hands Free Starting Access Electric Module	●	●	●	●
308 (T9)	Electric Key Reader	●	●	●	●
308 (T9)	Battery Charge Status Unit	●	●	●	●
308 (T9)	Voltage Retaining Device	●	●	●	●
308 (T9)	Matrix Screen Integral To The Instrument Panel	●	●	●	●
308 (T9)	Supply Protection And Management Unit	●	●	●	●
308 (T9)	Independent Telematic Unit (BTA)	●	●	●	●
308 (T9)	PADDGO INERGY	●	●	●	●
308 (T9)	Multifunction Display	●	●	●	●

308 (T9)	Multiplexed Control Panel	●	●	●	●
308 (T9)	External CD Player	●	●	●	●
308 (T9)	Telematic Unit/Radio Navigation	●	●	●	●
308 (T9)	Audio Amplifier	●	●	●	●
308 (T9)	Touch Screen	●	●	●	●
308 (T9)	Radio/Telephone	●	●	●	●
308 (T9)	Alarm	●	●	●	●
308 (T9)	Siren	●	●	●	●
308 (T9)	Radio	●	●	●	●
308 (S)	Engine Control Moduel	●	●	●	●
308 (S)	Auto Gearbox	●	●	●	●
308 (S)	Active Safety (ABS)	●	●	●	●
308 (S)	Airbag	●	●	●	●
308 (S)	Instrument Panel	●	●	●	●
308 (S)	Built-in System Interface (BSI)	●	●	●	●
308 (S)	Air Conditioning	●	●	●	●
308 (S)	Engine Relay Unit	●	●	●	●
308 (S)	Electric Power Steering	●	●	●	●
308 (S)	Electric Steering Lock	●	●	●	●
308 (S)	Steering Wheel Switching Module	●	●	●	●
308 (S)	Parking Assistance Module	●	●	●	●
308 (S)	Driver Seat Memory Unit	●	●	●	●
308 (S)	Directional Headlamps	●	●	●	●
308 (S)	Battery Charge Status Unit	●	●	●	●
308 (S)	Voltage Retaining Device	●	●	●	●
308 (S)	Hands Free Starting Access Electric Module	●	●	●	●
308 (S)	Electric Key Reader	●	●	●	●
308 (S)	Supply Protection And Management Unit	●	●	●	●
308 (S)	Rain/Brightness Sensor	●	●	●	●
308 (S)	Matrix Screen Integral To The Instrument Panel	●	●	●	●
308 (S)	Multiplexed Control Panel	●	●	●	●
308 (S)	Multifunction Display	●	●	●	●
308 (S)	Touch Screen	●	●	●	●
308 (S)	Telematic Unit	●	●	●	●
308 (S)	Radio/Telephone	●	●	●	●
308 (S)	Service Module	●	●	●	●
308 (S)	Alarm	●	●	●	●
308 (S)	Radio	●	●	●	●
405	Engine Control Moduel	●	●	●	●
406	Engine Control Moduel	●	●	●	●
406	Auto Gearbox	●	●	●	●
406	Active Safety (ABS)	●	●	●	●
406	Airbag	●	●	●	●
406	Instrument Panel	●	●	●	●
406	Built-in System Interface (BSI)	●	●	●	●
406	Air Conditioning	●	●	●	●
406	Diesel Additive Function	●	●	●	●
406	Steering Wheel Switching Module	●	●	●	●
406	Rain/Brightness Sensor	●	●	●	●
406	Multifunction Display	●	●	●	●
406	CD Player	●	●	●	●
406	Alarm	●	●	●	●
406	Radio	●	●	●	●
407	Engine Control Moduel	●	●	●	●
407	Auto Gearbox	●	●	●	●
407	Active Safety (ABS)	●	●	●	●
407	Airbag	●	●	●	●
407	Instrument Panel	●	●	●	●

407	Built-in System Interface (BSI)	●	●	●	●
407	Air Conditioning	●	●	●	●
407	Engine Relay Unit	●	●	●	●
407	Trailer Relay Unit	●	●	●	●
407	Diesel Additive Function	●	●	●	●
407	Electronically Managed Suspension	●	●	●	●
407	Electric Power Steering	●	●	●	●
407	Steering Wheel Switching Module	●	●	●	●
407	Parking Assistance Module	●	●	●	●
407	Driver Door module	●	●	●	●
407	Passenger Door Module	●	●	●	●
407	Driver Seat Memory Unit	●	●	●	●
407	Passenger Seat Memory Unit	●	●	●	●
407	Right Headlamp Beam Level Corrector	●	●	●	●
407	Left Headlamp Beam Level Corrector	●	●	●	●
407	Directional Headlamps	●	●	●	●
407	Rain/Brightness Sensor	●	●	●	●
407	Hands Free Control Unit	●	●	●	●
407	Battery Charge Status Unit	●	●	●	●
407	High Frequency Receiver	●	●	●	●
407	Under Inflation Detection	●	●	●	●
407	Multifunction Display	●	●	●	●
407	Display/Telematics	●	●	●	●
407	Sunroof	●	●	●	●
407	Windscreen Wiper	●	●	●	●
407	Additional Heating	●	●	●	●
407	Boot Wiring	●	●	●	●
407	CD Player	●	●	●	●
407	Alarm	●	●	●	●
407	Radio	●	●	●	●
408 (T73)	Engine Control Moduel	●	●	●	●
408 (T73)	Auto Gearbox	●	●	●	●
408 (T73)	Active Safety (ABS)	●	●	●	●
408 (T73)	Airbag	●	●	●	●
408 (T73)	Instrument Panel	●	●	●	●
408 (T73)	Built-in System Interface (BSI)	●	●	●	●
408 (T73)	Air Conditioning	●	●	●	●
408 (T73)	Engine Relay Unit	●	●	●	●
408 (T73)	Trailer Relay Unit	●	●	●	●
408 (T73)	Electric Power Steering	●	●	●	●
408 (T73)	Steering Wheel Switching Module	●	●	●	●
408 (T73)	Parking Assistance Module	●	●	●	●
408 (T73)	Driver Door Module	●	●	●	●
408 (T73)	Driver Seat Memory Unit	●	●	●	●
408 (T73)	Passenger Seat Memory Unit	●	●	●	●
408 (T73)	Rain/Brightness Sensor	●	●	●	●
408 (T73)	Display/Telematics	●	●	●	●
408 (T73)	Multiplexed Additive Adding Pump	●	●	●	●
408 (T73)	Hands Free Control Unit	●	●	●	●
408 (T73)	Service Module"	●	●	●	●
408 (T73)	Battery Charge Status Unit	●	●	●	●
408 (T73)	Multifunction Display	●	●	●	●
408 (T73)	Not Fastened Warning Light (TNB)	●	●	●	●
408 (T73)	High Frequency Receiver	●	●	●	●
408 (T73)	Lane Departure Warning System	●	●	●	●
408 (T73)	Matrix Screen Integral To The Instrument Panel	●	●	●	●
408 (T73)	Moving Panel Deflector	●	●	●	●
408 (T73)	Under Inflation Detection	●	●	●	●

408 (T73)	Driver School Module	●	●	●	●
408 (T73)	Directional Headlamps	●	●	●	●
408 (T73)	Windscreen Wiper	●	●	●	●
408 (T73)	Sunroof	●	●	●	●
408 (T73)	Folding Roof	●	●	●	●
408 (T73)	CD Player	●	●	●	●
408 (T73)	Radio	●	●	●	●
408 (T73)	Audio Amplifier	●	●	●	●
408 (T73)	Alarm	●	●	●	●
408 (T73)	Alarm	●	●	●	●
408 (T93)	Engine Control Moduel	●	●	●	●
408 (T93)	Auto Gearbox	●	●	●	●
408 (T93)	Active Safety (ABS)	●	●	●	●
408 (T93)	Airbag	●	●	●	●
408 (T93)	Instrument Panel	●	●	●	●
408 (T93)	Air Conditioning	●	●	●	●
408 (T93)	Engine Relay Unit	●	●	●	●
408 (T93)	Electric Power Steering	●	●	●	●
408 (T93)	Electric Steering Lock	●	●	●	●
408 (T93)	Steering Wheel Switching Module	●	●	●	●
408 (T93)	Parking Assistance Module	●	●	●	●
408 (T93)	Hands Free Starting Access Electric Module	●	●	●	●
408 (T93)	Electric Key Reader	●	●	●	●
408 (T93)	Battery Charge Status Unit	●	●	●	●
408 (T93)	Voltage Retaining Device	●	●	●	●
408 (T93)	Driver Seat Memory Unit	●	●	●	●
408 (T93)	Directional Headlamps	●	●	●	●
408 (T93)	Rain/Brightness Sensor	●	●	●	●
408 (T93)	Independent Telematic Unit (BTA)	●	●	●	●
408 (T93)	Matrix Screen Integral To The Instrument Panel	●	●	●	●
408 (T93)	Multifunction Display	●	●	●	●
408 (T93)	Supply Protection And Management Unit	●	●	●	●
408 (T93)	Telematic Unit/Radio Navigation	●	●	●	●
408 (T93)	Multiplexed Control Panel	●	●	●	●
408 (T93)	Touch Screen	●	●	●	●
408 (T93)	Radio/Telephone	●	●	●	●
408 (T93)	Alarm	●	●	●	●
408 (T93)	Radio	●	●	●	●
508	Engine Control Moduel	●	●	●	●
508	Auto Gearbox	●	●	●	●
508	Active Safety (ABS)	●	●	●	●
508	Electric Secondary Brake	●	●	●	●
508	Airbag	●	●	●	●
508	Instrument Panel	●	●	●	●
508	Built-in System Interface (BSI)	●	●	●	●
508	Air Conditioning	●	●	●	●
508	Rear Air Conditioning	●	●	●	●
508	Engine Relay Unit	●	●	●	●
508	Trailer Relay Unit	●	●	●	●
508	Electric Power Steering	●	●	●	●
508	Steering Wheel Switching Module	●	●	●	●
508	Steering Wheel With Fixed Central Control	●	●	●	●
508	Electric Steering Lock	●	●	●	●
508	Parking Assistance Module	●	●	●	●
508	Driver Door control panel	●	●	●	●
508	Driver Seat Memory Unit	●	●	●	●
508	Main Beams Assistant	●	●	●	●
508	Seat Belts Not Fastened LED Unit	●	●	●	●

508	Active Damper Electronic Unit	●	●	●	●
508	Traction Battery	●	●	●	●
508	Battery Charge Status Unit	●	●	●	●
508	Rain/Brightness Sensor (CDPL)	●	●	●	●
508	Hands Free Control Unit	●	●	●	●
508	Electric Key Reader	●	●	●	●
508	Matrix Screen Integral To The Instrument Panel	●	●	●	●
508	Multifunction Display	●	●	●	●
508	High Head Vision	●	●	●	●
508	Multiplexed Control Panel	●	●	●	●
508	Hybrid Control 1	●	●	●	●
508	Hybrid Control 2	●	●	●	●
508	Hybrid Mode Selector	●	●	●	●
508	Independent Telematic Unit (BTA)	●	●	●	●
508	Under Inflation Detection	●	●	●	●
508	Discharge Bulbs Vertical And Horizontal Adjustment	●	●	●	●
508	Additional Heating	●	●	●	●
508	Supply Protection And Management Unit	●	●	●	●
508	Windscreen Wiper (Right)	●	●	●	●
508	Windscreen Wiper (Left)	●	●	●	●
508	Telematic Navigator	●	●	●	●
508	Display/Telematics	●	●	●	●
508	Alarm	●	●	●	●
508	Audio Amplifier	●	●	●	●
508	Radio (RD5)	●	●	●	●
508	Motorised Boot	●	●	●	●
605	Engine Control Moduel	●	●	●	●
607	Engine Control Moduel	●	●	●	●
607	Auto Gearbox	●	●	●	●
607	Active Safety (ABS)	●	●	●	●
607	Airbag	●	●	●	●
607	Instrument Panel	●	●	●	●
607	Built-in System Interface (BSI)	●	●	●	●
607	Air Conditioning	●	●	●	●
607	Engine Relay Unit	●	●	●	●
607	Trailer Relay Unit	●	●	●	●
607	Diesel Additive Function	●	●	●	●
607	Electronically Managed Suspension	●	●	●	●
607	Electric Power Steering	●	●	●	●
607	Steering Wheel Switching Module	●	●	●	●
607	Parking Assistance Module	●	●	●	●
607	Driver Door control panel	●	●	●	●
607	Passenger Door Control Panel	●	●	●	●
607	Driver Seat Memory Unit	●	●	●	●
607	Headlamp Height Corrector	●	●	●	●
607	Hands Free Control Unit	●	●	●	●
607	Under Inflation Detection	●	●	●	●
607	Rain/Brightness Sensor	●	●	●	●
607	Storing Of The Driving Position	●	●	●	●
607	Multifunction Display	●	●	●	●
607	Telematic Unit	●	●	●	●
607	CD Player	●	●	●	●
607	Alarm	●	●	●	●
607	Radio	●	●	●	●
806	Engine Control Moduel	●	●	●	●
806	Auto Gearbox	●	●	●	●
806	Airbag	●	●	●	●
807	Engine Control Moduel	●	●	●	●

807	Auto Gearbox	●	●	●	●
807	Active Safety (ABS)	●	●	●	●
807	Airbag	●	●	●	●
807	Instrument Panel	●	●	●	●
807	Built-in System Interface (BSI)	●	●	●	●
807	Air Conditioning	●	●	●	●
807	Diesel Additive Function	●	●	●	●
807	Electric Power Steering (GEP)	●	●	●	●
807	Steering Wheel Switching Module	●	●	●	●
807	Parking Assistance Module	●	●	●	●
807	Driver Door Module	●	●	●	●
807	Passenger Door Module	●	●	●	●
807	Sliding Side Doors Module	●	●	●	●
807	Driver Seat Memory Unit	●	●	●	●
807	Left Headlamp Beam Level Corrector	●	●	●	●
807	Right Headlamp Beam Level Corrector	●	●	●	●
807	Warning Lights/Odometer unit	●	●	●	●
807	Telematic Receiver Control	●	●	●	●
807	Additional Heating	●	●	●	●
807	Hands Free Control Unit	●	●	●	●
807	Storing Of The Driving Position	●	●	●	●
807	Under Inflation Detection	●	●	●	●
807	Rain/Brightness Sensor	●	●	●	●
807	Rear Sunroof	●	●	●	●
807	Front Sunroof	●	●	●	●
807	Middle Sunroof	●	●	●	●
807	Multifunction Display	●	●	●	●
807	Display/Telematics	●	●	●	●
807	CD Player	●	●	●	●
807	Alarm	●	●	●	●
807	Radio	●	●	●	●
1007	Engine Control Moduel	●	●	●	●
1007	Manual Gearbox (BVMP)	●	●	●	●
1007	Active Safety (ABS)	●	●	●	●
1007	Airbag	●	●	●	●
1007	Instrument Panel	●	●	●	●
1007	Built-in System Interface (BSI)	●	●	●	●
1007	Air Conditioning	●	●	●	●
1007	Electric Power Steering	●	●	●	●
1007	Steering Wheel Switching Module	●	●	●	●
1007	Parking Assistance Module	●	●	●	●
1007	Sliding Side Doors Module	●	●	●	●
1007	Rain/Brightness Sensor	●	●	●	●
1007	Hands Free Control Unit	●	●	●	●
1007	Multiplexed Additive Adding Pump	●	●	●	●
1007	Under Inflation Detection	●	●	●	●
1007	Multifunction Display	●	●	●	●
1007	Radio	●	●	●	●
1007	CD Player	●	●	●	●
1007	Telematic Unit	●	●	●	●
1007	Alarm	●	●	●	●
2008	Engine Control Moduel	●	●	●	●
2008	Auto Gearbox	●	●	●	●
2008	Active Safety (ABS)	●	●	●	●
2008	Airbag	●	●	●	●
2008	Instrument Panel	●	●	●	●
2008	Air Conditioning	●	●	●	●
2008	Trailer Relay Unit	●	●	●	●

2008	Electric Power Steering	●	●	●	●
2008	Steering Wheel Switching Module	●	●	●	●
2008	Steering Wheel With Fixed Central Control	●	●	●	●
2008	Parking Assistance Module	●	●	●	●
2008	Rain/Brightness Sensor	●	●	●	●
2008	Multiplexed Control Panel	●	●	●	●
2008	Battery Charge Status Unit	●	●	●	●
2008	Independent Telematic Unit (BTA)	●	●	●	●
2008	Matrix Screen Integral To The Instrument Panel	●	●	●	●
2008	Multiplexed Additive Adding Pump	●	●	●	●
2008	Siren	●	●	●	●
2008	Telematic Unit	●	●	●	●
2008	External CD Player	●	●	●	●
2008	Alarm	●	●	●	●
2008	Audio Amplifier	●	●	●	●
2008	Radio	●	●	●	●
3008	Engine Control Moduel	●	●	●	●
3008	Auto Gearbox	●	●	●	●
3008	Active Safety (ABS)	●	●	●	●
3008	Electric Secondary Brake	●	●	●	●
3008	Airbag	●	●	●	●
3008	Instrument Panel	●	●	●	●
3008	Built-in System Interface (BSI)	●	●	●	●
3008	Air Conditioning	●	●	●	●
3008	Engine Relay Unit	●	●	●	●
3008	Trailer Relay Unit	●	●	●	●
3008	Electric Power Steering	●	●	●	●
3008	Steering Wheel Switching Module	●	●	●	●
3008	Parking Assistance Module	●	●	●	●
3008	Driver Door control panel	●	●	●	●
3008	Not Fastened Warning Light (TNB)	●	●	●	●
3008	Headlamp Height Corrector	●	●	●	●
3008	Traction Battery	●	●	●	●
3008	Battery Charge Status Unit	●	●	●	●
3008	Hands Free Control Unit	●	●	●	●
3008	Rain/Brightness Sensor	●	●	●	●
3008	Display/Telematics	●	●	●	●
3008	Multiplexed Additive Adding Pump	●	●	●	●
3008	Service Module	●	●	●	●
3008	Multifunction Display	●	●	●	●
3008	High Head Vision	●	●	●	●
3008	Network Isolation Unit	●	●	●	●
3008	High Frequency Receiver	●	●	●	●
3008	Matrix Screen Integral To The Instrument Panel	●	●	●	●
3008	Under Inflation Detection	●	●	●	●
3008	Assistance In Complying With The Inter Vehicle Time	●	●	●	●
3008	Anti-slip Mode Selector	●	●	●	●
3008	Hybrid Control 1	●	●	●	●
3008	Hybrid Control 2	●	●	●	●
3008	Hybrid Mode Selector	●	●	●	●
3008	Windscreen Wiper	●	●	●	●
3008	CD Player	●	●	●	●
3008	Audio Amplifier	●	●	●	●
3008	Radio	●	●	●	●
3008	Alarm	●	●	●	●
4007	Engine Control Moduel	●	●	●	●
4007	Auto Gearbox	●	●	●	●
4007	ABS/ESP	●	●	●	●

4007	Airbag	●	●	●	●
4007	Instrument Panel	●	●	●	●
4007	Built-in System Interface (BSI)	●	●	●	●
4007	Air Conditioning	●	●	●	●
4007	Steering Wheel Angle Sensor	●	●	●	●
4007	Gear Lever (DCT)	●	●	●	●
4007	4x4 Transmission	●	●	●	●
4007	Parking Assistance Module	●	●	●	●
4007	Coded Anti Start	●	●	●	●
4007	Rear Final Drive Piloted Clutch	●	●	●	●
4007	Hands Free Control Unit	●	●	●	●
4007	Static AFS	●	●	●	●
4007	Navigation	●	●	●	●
4007	Radio	●	●	●	●
4008	Auto Gearbox	●	●	●	●
4008	Airbag	●	●	●	●
4008	Instrument Panel	●	●	●	●
4008	Air Conditioning	●	●	●	●
4008	Electric Power Steering	●	●	●	●
4008	Steering Wheel Angle Sensor	●	●	●	●
4008	Parking Assistance Module	●	●	●	●
4008	Hands Free Control Unit	●	●	●	●
4008	Rear Final Drive Piloted Clutch	●	●	●	●
4008	Starting Authorisation	●	●	●	●
4008	Start/Stop Control	●	●	●	●
4008	Radio/Telephone	●	●	●	●
4008	Navigation	●	●	●	●
5008	Engine Control Moduel	●	●	●	●
5008	Auto Gearbox	●	●	●	●
5008	Active Safety (ABS)	●	●	●	●
5008	Electric Parking Brake	●	●	●	●
5008	Electric Secondary Brake	●	●	●	●
5008	Airbag	●	●	●	●
5008	Instrument Panel	●	●	●	●
5008	Built-in System Interface (BSI)	●	●	●	●
5008	Air Conditioning	●	●	●	●
5008	Engine Relay Unit	●	●	●	●
5008	Trailer Relay Unit	●	●	●	●
5008	Electric Power Steering	●	●	●	●
5008	Steering Wheel Switching Module	●	●	●	●
5008	Parking Assistance Module	●	●	●	●
5008	Driver Door control panel	●	●	●	●
5008	Not Fastened Warning Light (TNB)	●	●	●	●
5008	Headlamp Height Corrector	●	●	●	●
5008	Battery Charge Status Unit	●	●	●	●
5008	Rain/Brightness Sensor	●	●	●	●
5008	Hands Free Control Unit	●	●	●	●
5008	Multiplexed Additive Adding Pump	●	●	●	●
5008	Service Module	●	●	●	●
5008	High Head Vision	●	●	●	●
5008	Network Isolation Unit	●	●	●	●
5008	High Frequency Receiver	●	●	●	●
5008	Control Panel Dot Matrix Display	●	●	●	●
5008	Under Inflation Detection	●	●	●	●
5008	Assistance In Complying With The Inter Vehicle Time	●	●	●	●
5008	Anti-slip Mode Selector	●	●	●	●
5008	Lane Departure Warning System	●	●	●	●
5008	Windscreen Wiper	●	●	●	●

5008	Portable Unit	●	●	●	●
5008	Multifunction Display	●	●	●	●
5008	Display/Telematics	●	●	●	●
5008	CD Player	●	●	●	●
5008	Audio Amplifier	●	●	●	●
5008	Radio	●	●	●	●
5008	Alarm	●	●	●	●
5008	Steering Wheel With Fixed Central Control	●	●	●	●
5008	Multiplexed Control Panel	●	●	●	●
5008	Hybrid Mode Selector	●	●	●	●
5008	Independent Telematic Unit (BTA)	●	●	●	●
5008	Discharge Bulbs Vertical And Horizontal Adjustment	●	●	●	●
iON	Electric Vehicle Management	●	●	●	●
iON	Electric Machine Management	●	●	●	●
iON	Active Safety (ABS)	●	●	●	●
iON	Airbag	●	●	●	●
iON	Instrument Panel	●	●	●	●
iON	Electric Power Steering	●	●	●	●
iON	Steering Wheel Angle Sensor	●	●	●	●
iON	Passenger Compartment Air Heating Resistor	●	●	●	●
iON	Gateway Wiring Housing	●	●	●	●
iON	Onboard Charger Of The Traction Battery	●	●	●	●
iON	Independent Telematic Unit (BTA)	●	●	●	●
iON	Direct Voltage Transformer	●	●	●	●
iON	Traction Battery	●	●	●	●
iON	Traction Battery Cells Management 01	●	●	●	●
iON	Traction Battery Cells Management 02	●	●	●	●
iON	Traction Battery Cells Management 03	●	●	●	●
iON	Traction Battery Cells Management 04	●	●	●	●
iON	Traction Battery Cells Management 05	●	●	●	●
iON	Traction Battery Cells Management 07	●	●	●	●
iON	Traction Battery Cells Management 08	●	●	●	●
iON	Traction Battery Cells Management 09	●	●	●	●
iON	Traction Battery Cells Management 10	●	●	●	●
iON	Traction Battery Cells Management 11	●	●	●	●
iON	Radio	●	●	●	●
HOGGAR	Engine Control Moduel	●	●	●	●
HOGGAR	Auto Gearbox	●	●	●	●
HOGGAR	Active Safety (ABS)	●	●	●	●
HOGGAR	Airbag	●	●	●	●
HOGGAR	Instrument Panel	●	●	●	●
HOGGAR	Built-in System Interface (BSI)	●	●	●	●
HOGGAR	Air Conditioning	●	●	●	●
HOGGAR	Electric Power Steering	●	●	●	●
HOGGAR	Steering Wheel Switching Module	●	●	●	●
HOGGAR	Rain/Brightness Sensor	●	●	●	●
HOGGAR	Stolen Vehicle Location Control Unit	●	●	●	●
HOGGAR	Multifunction Display	●	●	●	●
HOGGAR	Service Module	●	●	●	●
HOGGAR	CD Player	●	●	●	●
HOGGAR	Radio	●	●	●	●
HOGGAR	Alarm	●	●	●	●
RCZ	Engine Control Moduel	●	●	●	●
RCZ	Auto Gearbox	●	●	●	●
RCZ	Active Safety (ABS)	●	●	●	●
RCZ	Airbag	●	●	●	●
RCZ	Instrument Panel	●	●	●	●
RCZ	Built-in System Interface (BSI)	●	●	●	●

RCZ	Air Conditioning	●	●	●	●
RCZ	Engine Relay Unit	●	●	●	●
RCZ	Trailer Relay Unit	●	●	●	●
RCZ	Electric Power Steering	●	●	●	●
RCZ	Steering Wheel Switching Module	●	●	●	●
RCZ	Parking Assistance Module	●	●	●	●
RCZ	Driver Door Module	●	●	●	●
RCZ	Driver Seat Memory Unit	●	●	●	●
RCZ	Passenger Seat Memory Unit	●	●	●	●
RCZ	Not Fastened Warning Light (TNB)	●	●	●	●
RCZ	Directional Headlamps	●	●	●	●
RCZ	Hands Free Control Unit	●	●	●	●
RCZ	Battery Charge Status Unit	●	●	●	●
RCZ	High Frequency Receiver	●	●	●	●
RCZ	Lane Departure Warning System	●	●	●	●
RCZ	Rain/Brightness Sensor	●	●	●	●
RCZ	Display/Telematics	●	●	●	●
RCZ	Multiplexed Additive Adding Pump	●	●	●	●
RCZ	Matrix Screen Integral To The Instrument Panel	●	●	●	●
RCZ	Service Module"	●	●	●	●
RCZ	Multifunction Display	●	●	●	●
RCZ	Moving Panel Deflector	●	●	●	●
RCZ	Under Inflation Detection	●	●	●	●
RCZ	Driver School Module	●	●	●	●
RCZ	Sunroof	●	●	●	●
RCZ	Folding Roof	●	●	●	●
RCZ	Windscreen Wiper	●	●	●	●
RCZ	CD Player	●	●	●	●
RCZ	Radio	●	●	●	●
RCZ	Alarm	●	●	●	●
RCZ	Alarm	●	●	●	●
RCZ	Audio Amplifier	●	●	●	●
BIPPER	Auto Gearbox	●	●	●	●
BIPPER	Active Safety (ABS)	●	●	●	●
BIPPER	Airbag	●	●	●	●
BIPPER	Instrument Panel	●	●	●	●
BIPPER	Parking Assistance Module	●	●	●	●
BOXER	Engine Control Moduel	●	●	●	●
BOXER	Auto Gearbox (4HP20)	●	●	●	●
BOXER	Active Safety (ABS)	●	●	●	●
BOXER	Electric Power Steering	●	●	●	●
BOXER	Additional Heating	●	●	●	●
BOXER	Tachograph	●	●	●	●
EXPERT	Engine Control Moduel	●	●	●	●
EXPERT	Auto Gearbox	●	●	●	●
EXPERT	Active Safety (ABS)	●	●	●	●
EXPERT	Airbag	●	●	●	●
EXPERT	Instrument Panel	●	●	●	●
EXPERT	Built-in System Interface (BSI)	●	●	●	●
EXPERT	Air Conditioning	●	●	●	●
EXPERT	Rear Air Conditioning	●	●	●	●
EXPERT	Engine Relay Unit	●	●	●	●
EXPERT	Trailer Relay Unit	●	●	●	●
EXPERT	Electric Power Steering	●	●	●	●
EXPERT	Steering Wheel Switching Module	●	●	●	●
EXPERT	Parking Assistance Module	●	●	●	●
EXPERT	Battery Charge Status Unit	●	●	●	●
EXPERT	Rain/Brightness Sensor	●	●	●	●

EXPERT	Additional Heating	●	●	●	●
EXPERT	Anti-slip Mode Selector	●	●	●	●
EXPERT	Hands Free Control Unit	●	●	●	●
EXPERT	High Frequency Receiver	●	●	●	●
EXPERT	Pneumatic Suspension	●	●	●	●
EXPERT	Deflation Detection (DSG)	●	●	●	●
EXPERT	Bodywork Conversion Unit	●	●	●	●
EXPERT	Display/Telematics	●	●	●	●
EXPERT	Multifunction Display	●	●	●	●
EXPERT	CD Player	●	●	●	●
EXPERT	Radio	●	●	●	●
EXPERT	Alarm	●	●	●	●
PARTNER	Engine Control Moduel	●	●	●	●
PARTNER	Auto Gearbox	●	●	●	●
PARTNER	Active Safety (ABS)	●	●	●	●
PARTNER	Airbag	●	●	●	●
PARTNER	Instrument Panel	●	●	●	●
PARTNER	Built-in System Interface (BSI)	●	●	●	●
PARTNER	Air Conditioning	●	●	●	●
PARTNER	Air Conditioning	●	●	●	●
PARTNER	Engine Relay Unit	●	●	●	●
PARTNER	Trailer Relay Unit	●	●	●	●
PARTNER	Electric Power Steering	●	●	●	●
PARTNER	Steering Wheel Switching Module	●	●	●	●
PARTNER	Parking Assistance Module	●	●	●	●
PARTNER	Passenger Compartment Air Heating Resistor	●	●	●	●
PARTNER	Hands Free Control Unit	●	●	●	●
PARTNER	Rain/Brightness Sensor	●	●	●	●
PARTNER	Onboard Charger Of The Traction Battery	●	●	●	●
PARTNER	Bodywork Conversion Unit	●	●	●	●
PARTNER	Electric Machine Management	●	●	●	●
PARTNER	High Frequency Receiver	●	●	●	●
PARTNER	Under Inflation Detection	●	●	●	●
PARTNER	Anti-slip Mode Selector	●	●	●	●
PARTNER	Additional Heating	●	●	●	●
PARTNER	Battery Charge Status Unit	●	●	●	●
PARTNER	Traction Battery Cells Management 01	●	●	●	●
PARTNER	Traction Battery Cells Management 02	●	●	●	●
PARTNER	Traction Battery Cells Management 03	●	●	●	●
PARTNER	Traction Battery Cells Management 04	●	●	●	●
PARTNER	Traction Battery Cells Management 05	●	●	●	●
PARTNER	Traction Battery Cells Management 07	●	●	●	●
PARTNER	Traction Battery Cells Management 08	●	●	●	●
PARTNER	Traction Battery Cells Management 09	●	●	●	●
PARTNER	Traction Battery Cells Management 10	●	●	●	●
PARTNER	Multifunction Display	●	●	●	●
PARTNER	Display/Telematics	●	●	●	●
PARTNER	Multiplexed Additive Adding Pump	●	●	●	●
PARTNER	Service Module"	●	●	●	●
PARTNER	CD Player	●	●	●	●
PARTNER	Alarm	●	●	●	●
PARTNER	Radio	●	●	●	●