CR MAX

SEAT

SEAT Diagnostic Function List(Note:For reference only)

NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

| Vehicle | llis vers | 1011. | | V | ear | | |
|------------------------------------|-----------|----------------------------|-------|------|------------------|---------|------------|
| Alhambra | | | | | | | |
| Altea | + | 2001 - 2019 2004 - 2015 | | | | | |
| Ateca | + | | | | | | |
| Arosa | _ | | | | - 2019 - 2004 | | |
| Cordoba | _ | | | | - 2004 - 2009 | | |
| Exeo | + | | | | - 2009 - 2014 | | |
| Ibiza | + | | | | - 2014 - 2019 | | |
| Inca | | | | | - 2003 | | |
| Leon | | | | | - 2003 - 2019 | | |
| Mii | | | | | - 2019 - 2019 | | |
| Toledo | | | | | - 2010 | | |
| Toledo | | | | | - 2019 | | |
| | EcuInfo | Read | Erase | Live | Actuation | Rasic | |
| Systemlist | | Codes | Codes | Data | Test | Setting | Adaptation |
| 01 Engine Control Module 1 | • | • | • | • | • | • | • |
| 02 Transmission Control Module | • | • | • | • | • | • | • |
| 03 Brakes 1 | • | • | • | • | • | • | • |
| 04 Steering Angle Sender | • | • | • | • | • | • | • |
| 05 Kessy | • | • | • | • | • | 0 | 0 |
| 06 Seat Adjustment Passenger Side | • | • | • | • | • | 0 | 0 |
| 07 Display Control Unit | • | • | • | • | • | 0 | 0 |
| 08 Air Conditioning | • | • | • | • | • | • | • |
| 09 Central Electrics | • | • | • | • | • | • | • |
| OB Auxiliary Air Heater | • | • | • | • | • | 0 | 0 |
| OC Rear Axle Steering 2 | • | • | • | • | • | 0 | 0 |
| OD Sliding Door Left | • | • | • | • | • | 0 | 0 |
| OE Media Player Position 1 | • | • | • | • | • | 0 | 0 |
| OF Radio Tuner - Digital | • | • | • | • | • | 0 | 0 |
| 10 Parking Assistance 2 | • | • | • | • | • | 0 | 0 |
| 11 Engine Control Module 2 | • | • | • | • | • | 0 | 0 |
| 12 Clutch Control Unit | • | • | • | • | • | 0 | 0 |
| 13 Adaptive Cruise Control | • | • | • | • | • | 0 | 0 |
| 14 Wheel Dampening Electronics | • | • | • | • | • | 0 | 0 |
| 15 Airbag | • | • | • | • | • | • | • |
| 16 Steering Column Electronics | • | • | • | • | • | • | • |
| 17 Dash Board | • | • | • | • | • | • | • |
| 18 Auxiliary Parking Heater | | • | • | • | • | 0 | 0 |
| 19 Gateway | | • | • | • | • | • | • |
| 1A Fuel Cell Engine | | • | • | • | • | 0 | 0 |
| 1B Active Steering | • | • | • | • | • | 0 | 0 |
| 1C Vehicle Position Detection | | • | | • | • | 0 | 0 |
| 1D Driver Identification | • | • | • | • | • | 0 | 0 |
| 1E Media Player Position 2 | • | • | • | • | • | 0 | 0 |
| 20 High Beam Assistance | • | | • | • | • | 0 | 0 |
| 21 Battery Energy Control Module 2 | • | • | • | • | • | 0 | 0 |
| 22 All Wheel Control | • | • | • | • | • | 0 | 0 |
| 23 Brake Boost | • | | | • | • | 0 | 0 |
| 25 Immobilizer | | | | • | • | 0 | 0 |
| 20 IUIIIONIIIZCI | | | | | | | |

| 28 Clisate Control Unit Rear | 26 Electronic Roof Control | | | | • | • 0 | 0 |
|--|----------------------------|----------------|---|---|---|-----|----------|
| 28 Climate Control Unit Rear 29 Light Control Left 30 Control Unit Wireless Charging 40 Control Unit Wireless Charging 50 Special Function 2 50 Special Function 2 51 Engine Electronics 50 Control World System 51 Ridge Control System 52 Control Unit Control World System 53 All Old Systems 54 Ridge Control System 55 Control Control World System 56 Control Right 57 Navigation 58 Special Function 59 Special Function 50 Control World System 50 Control World System 50 Control World System 50 Control World System 51 System System 52 Control Control World System 53 All Gold Control World System 54 Special Control World System 55 Control Right 56 Control Right 57 Navigation 58 Special Function 59 Special Function 50 Control World System 50 Control World System 50 Control Right 50 Control Right 50 Control Right 50 Control Right 51 Special Function 50 Control World System 51 Special Function 50 Control World System 51 Special Function 52 Lane Change Assistant 51 Control Right 52 Special Function 53 Special Function 54 Control World System 55 Special Function 56 Control World System 57 System System 58 Special Function 59 Special Function 50 Control World System 50 Control World System 50 Control World System 50 Control Module 51 Dirly World System 53 Special Function World System 54 Rear Light 54 Rear Light 55 Read Myustment Rear Driver Side 56 Control Module 57 Ty Tuner 58 Function Module 59 Door Electronics Passenger Side 50 Special Function World System 50 Control World Rear Passenger Side 50 Special Function System 50 Control World Rear Passenger Side 50 Special Function System 50 Control World Rear Passenger Side 50 Control Supply 50 Control Rear Passenger Side 50 Control Supply 50 Control Rear Passenger Side 50 Control Rear Passenge | | | • | • | • | | |
| 28 Light Control Left 20 Control Unit Wireless Charging 20 Voice Amplifier 20 Voice Amplifier 21 Notice Amplifier 22 Notice Amplifier 23 Notice Amplifier 24 Notice Amplifier 25 Notice Amplifier 26 Notice Amplifier 27 Notice Amplifier 28 Notice Amplifier 29 Notice Amplifier 20 Notice Amplifier 20 Notice Amplifier 20 Notice Amplifier 20 Notice Amplifier 21 Notice Amplifier 22 Notice Amplifier 23 Notice Amplifier 24 Notice Amplifier 25 Notice Amplifier 26 Notice Amplifier 27 Notice Amplifier 28 Notice Amplifier 28 Notice Amplifier 29 Notice Amplifier 20 Notice Amplifier 21 Notice Amplifier 22 Notice Amplifier 23 Notice Amplifier 24 Notice Amplifier 25 Notice Amplifier 26 Notice Amplifier 26 Notice Amplifier 26 Notice Amplifier 27 Notice Amplifier 28 Notice Amplifier 28 Notice Amplifier 29 Notice Amplifier 20 Notice Amplifier 21 Notice Amplifier 21 Notice Amplifier 22 Notice Amplifier 23 Notice Amplifier 24 Notice Amplifier 25 Notice Amplifier 26 Notice Amplifier 27 Notice Amplifier 28 Notice Amplifier 28 Notice Amplifier 29 Notice Amplifier 20 Notice Am | | | | | | | |
| 28 Steering Column Locking | | | • | • | • | | |
| 28 Steering Column Locking | | • | • | • | • | | |
| 20 Voice Amplifier | | | • | • | • | | |
| 2E Media Player Position 3 | | • | • | • | • | | |
| 30 Special Function 2 | · | | • | • | • | | |
| 31 Engine Electronics | | • | • | • | • | | |
| 32 Lock Electronics | | • | • | • | • | | |
| 33 All OGD Systems | | • | • | • | • | | |
| 34 Ride Control System | | | • | • | • | | |
| 35 Central Locking Control Module | | • | • | _ | • | | |
| 36 Seat Adjustment Driver Side | | | • | • | • | | |
| 37 Navigation | | | • | • | • | | |
| 38 Roof Electronic Control Module | | | | • | | | |
| 39 Light Control Right | | | • | • | | | |
| 3A Special Vehicle Assistant | | | | | | | |
| 3B Sensor Electronics | | | | _ | | | |
| 3C Lane Change Assistant | - | | • | • | | | |
| 3D Special Function | | | | | | | |
| 3E Media Player Position 4 | | | • | | | | |
| 3F Dynamic Assembly Mounting | | + - | | | | | |
| 40 Air Conditioning Compressor | | + - | | | | | |
| 1 Diesel Pump Electronics | | | | _ | | | |
| 42 Door Electronics Driver Side O O 43 Bremskraftunterstutzung O O 44 Steering Assistance O O 45 Interior Monitoring O O 46 Central Module Comfort System O O 47 Sound System O O 48 Seat Adjustment Rear Driver Side O O 48 Raar Light O O 48 Multifunction Module O O 4C Tire Pressure Monitoring 2 O O 4D Data Transfer Car2X_XXX O O 4E Control Read Rear Right O O 4F Central Electrics 2 O O 50 Seat Adjustment 3rd Row O O 51 Drive Motor Control Module O O 52 Door Electronics Passenger Side O O 54 Rear Spoiler O O 55 Headlight Regulation O O 56 Radio O O 57 TV Tuner O O 58 Fuel Supply O O <td></td> <td>+ -</td> <td></td> <td></td> <td></td> <td></td> <td></td> | | + - | | | | | |
| 43 Bremskraftunterstutzung | | | • | • | | | |
| 44 Steering Assistance • • • • • • • • • • • • • • • • • • • | | • | • | _ | | | |
| 45 Interior Monitoring • • • • • • • • • • • • • • • • • • • | | • | • | • | • | | |
| 46 Central Module Comfort System • • • • • • • • • • • • • • • • • • • | | | • | • | • | | <u>-</u> |
| 47 Sound System • • • • • • • • • • • • • • • • • • • | | | • | • | • | • • | • |
| 48 Seat Adjustment Rear Driver Side Image: Control of the control of th | | | • | • | • | • 0 | 0 |
| 4A Rear Light • • • • • • • • • • • • • • • • • • • | | | • | • | • | | |
| ## Multifunction Module | | • | • | | _ | | |
| ## C Tire Pressure Monitoring 2 | | • | • | • | • | | |
| 4D Data Transfer Car2X_XXX ● ● ● ○ ○ 4E Control Head Rear Right ● ● ● ○ ○ 4F Central Electrics 2 ● ● ● ○ ○ 50 Seat Adjustment 3rd Row ● ● ● ○ ○ 51 Drive Motor Control Module ● ● ● ○ ○ 52 Door Electronics Passenger Side ● ● ● ● ○ ○ 53 Parking Brake ● | | • | • | • | • | | |
| 4E Control Head Rear Right • • • • • • • • • • • • • • • • • • • | _ | | • | | | | |
| 4F Central Electrics 2 • • • • • • • • • • • • • • • • • • • | _ | • | • | • | | | |
| 50 Seat Adjustment 3rd Row ● ● ● ○ ○ 51 Drive Motor Control Module ● ● ● ○ ○ 52 Door Electronics Passenger Side ● ● ● ● ● 53 Parking Brake ● ● ● ● ● ● 54 Rear Spoiler ● <td></td> <td>•</td> <td>•</td> <td>•</td> <td>•</td> <td></td> <td></td> | | • | • | • | • | | |
| 51 Drive Motor Control Module • • • • • • • • • • • • • • • • • • • | | • | • | • | - | | |
| 52 Door Electronics Passenger Side • • • • • • • • • • • • • • • • • • • | | • | • | • | • | | |
| 53 Parking Brake • • • • • • • • • • • • • • • • • • • | | • | • | • | • | | |
| 54 Rear Spoiler • • • • • • • • • • • • • • • • • • • | | + | • | | | - | |
| 55 Headlight Regulation • • • • • • • • • • • • • • • • • • • | | + - | | | | - | |
| 56 Radio • • • • • • • • • • • • • • • • • • • | | + - | • | | | | |
| 57 TV Tuner • • • • • • ○ ○ 58 Fuel Supply • • • • • ○ ○ 5A Longitudinal Control • • • • • ○ ○ 5B Seat Adjustment Rear Passenger Side • • • • • ○ ○ 5C Lane Departure Warning System • • • • • ○ ○ 5D Operation • • • • ○ ○ | | • | • | | | | |
| 58 Fuel Supply • • • • • • • • • • • • • • • • • • • | | • | • | • | | | |
| 5A Longitudinal Control • • • • • • • • • • • • • • • • • • • | | • | • | • | | | |
| 5B Seat Adjustment Rear Passenger Side • • • • • • • • • • • • • • • • • • • | | • | • | • | • | | |
| 5C Lane Departure Warning System • < | | • | • | • | • | | |
| 5D Operation | | • | • | • | | | |
| | | • | • | • | | | |
| , | • | • | • | • | • | _ | |
| 5F Information Control Unit 1 • • • • • O | | • | • | • | | | |

| 60 Tachograph | • | • | • | • | • | | 0 |
|---|---|--|---|---|---|-----|---|
| 61 Battery Regulation | • | • | • | • | • | • | • |
| 62 Door Electronics Rear Left | • | | • | • | • | 0 | 0 |
| 63 Entry Assistance Driver Side | • | • | • | • | • | 0 | 0 |
| 64 Stabilizers | • | • | • | • | • | 0 | 0 |
| 65 Tire Pressure Monitoring 1 | • | • | • | • | • | 0 | 0 |
| 66 Seat Adjustment Rear | • | • | • | • | • | 0 | 0 |
| 67 Voice Control | • | • | • | • | • | 0 | 0 |
| 68 Wiper Control Unit | • | • | • | • | • | 0 | 0 |
| 69 Trailer Function | • | • | • | • | • | 0 | 0 |
| 6A Door Automatic Rear Driver Side | • | • | • | • | • | 0 | 0 |
| 6B Aerodynamics Control Unit | • | | • | • | • | 0 | 0 |
| 6C Camera System Rear View | • | • | • | • | • | 0 | 0 |
| 6D Deck Lid Control Unit | • | | • | • | • | 0 | 0 |
| 6E Display Control Roof | • | • | • | • | • | 0 | 0 |
| 6F Central Module Comfort System 2 | • | | • | • | • | 0 | 0 |
| 71 Battery Charger | • | • | • | • | • | 0 | 0 |
| 72 Door Electronics Rear Right | • | • | • | • | • | 0 | 0 |
| 73 Entry Assistance Passenger Side | • | • | • | • | • | 0 | 0 |
| 74 Chassis Control | • | • | • | • | • | 0 | 0 |
| 75 Telematics Communication Unit | • | • | • | • | • | 0 | 0 |
| 76 Parking Assistance | • | • | • | • | • | • | • |
| 77 Telephone | • | • | • | • | • | 0 | 0 |
| 78 Sliding Door Right | • | • | • | • | • | 0 | 0 |
| 7A Door Automatic Rear Passenger Side | • | • | • | • | • | 0 | 0 |
| 7D Auxiliary Heater | • | • | • | • | • | 0 | 0 |
| 7E Dash Board Display Unit | • | • | • | • | • | 0 | 0 |
| 7F Information Control Unit 2 | • | • | • | • | • | 0 | 0 |
| 80 Battery Regulation Auxiliary Accumulator | • | • | • | • | • | 0 | 0 |
| 81 Gear Shift Control Module | • | | • | • | • | 0 | 0 |
| 82 Head Up Display | • | • | • | • | • | 0 | 0 |
| 84 Night Vision | • | • | • | • | • | 0 | 0 |
| 85 On-Board Camera | • | • | • | • | • | 0 | 0 |
| 87 Lane Assist LT3 | • | • | • | • | • | 0 | 0 |
| 88 Multi Contour Seat Driver Side | • | • | • | • | • | 0 | 0 |
| 89 Multi Contour Seat Passenger Side | • | • | • | • | • | 0 | 0 |
| 8A Multi Contour Seat Rear Driver Side | • | • | • | • | • | 0 | 0 |
| 8B Adaptive Cruise Control 2 | • | • | • | • | • | 0 | 0 |
| 8C Battery Energy Control Module | • | • | • | • | • | 0 | 0 |
| 8D Multi Contour Seat Rear Passenger Side | • | • | • | • | • | 0 | 0 |
| 8E Image Processing Electronics | • | • | • | • | • | 0 | 0 |
| 8F Pretensioner Front Left | • | • | • | • | • | 0 | 0 |
| 90 Pretensioner Front Right | • | • | • | • | • | 0 | 0 |
| 91 Engine Control Module (ECM) | • | • | • | • | • | 0 | 0 |
| 92 Transmission Electronics | • | • | • | • | • | 0 | 0 |
| 93 Immobilizer | • | • | • | • | • | 0 | 0 |
| 94 Airbag (SRS) | • | • | • | • | • | 0 | 0 |
| 95 Electronic Stability Program | • | • | • | • | • | 0 | 0 |
| 96 Instrument Cluster | • | • | • | • | • | 0 | 0 |
| | + | | • | • | • | 0 | 0 |
| 197 Tachograph | | | | | | | |
| 97 Tachograph 98 Tire Pressure Monitoring | • | | • | • | • | + + | 0 |
| 98 Tire Pressure Monitoring | • | • | • | • | • | 0 | 0 |
| | • | • | • | • | • | + + | 0 |

| 9C A/C Electronics | | | • | | | T 0 T | |
|---|---|---|--|---|----------|------------|---|
| 9D Auxiliary Heater (Fuel) | | | | • | | 0 | 0 |
| | | _ | | | | + <u> </u> | |
| 9E Auxiliary Heater (Electric) | • | _ | | • | | 0 | 0 |
| 9F Parking Heater, Water | • | _ | • | • | | 0 | 0 |
| A0 Audio 5 Radio, | • | • | • | • | | 0 | 0 |
| Al Navigation | • | • | • | • | | 0 | 0 |
| A2 CD Changer | • | • | • | • | • | 0 | 0 |
| A3 Telephone | • | • | • | • | | 0 | 0 |
| A5 Front Sensors Driver Assistance System | • | • | • | • | | 0 | 0 |
| A6 Microphone Control Unit | • | • | • | • | • | 0 | 0 |
| A7 Infotainment Interface | • | • | • | • | • | 0 | 0 |
| A8 External Communication Interface | • | • | • | • | • | 0 | 0 |
| A9 Actuator For Structure-Borne Sound | • | • | • | • | • | 0 | 0 |
| AA Wheel Brake Rear Right | • | • | • | • | • | 0 | 0 |
| AB Wheel Brake Rear Left | • | • | • | • | • | 0 | 0 |
| AC Reductant Control Module | • | • | • | • | • | 0 | 0 |
| AD Sensors Brake Systems | • | • | • | • | • | 0 | 0 |
| AE Telemetry Diagnostic Control Unit | • | • | • | • | • | 0 | 0 |
| BU Koof Display/control Head (Koof Control | • | • | • | • | • | 0 | 0 |
| B1 Upper Operating Field | • | • | • | • | • | 0 | 0 |
| B2 Parking Aid | • | • | • | • | • | 0 | 0 |
| B3 Trailer Function | • | • | • | • | • | 0 | 0 |
| B4 Vehicle Electrical System Control Module | • | • | • | • | • | 0 | 0 |
| B5 Programmable Special Module | • | • | • | • | • | 0 | 0 |
| B6 Steering Column Jacket Switch Module | • | • | • | • | • | 0 | 0 |
| B7 Access Startsystem Interface | • | • | • | • | • | 0 | 0 |
| B8 Electronic Roof Control 2 | • | • | • | • | • | 0 | 0 |
| B9 Auxiliary Display Control Unit | • | • | • | • | • | 0 | 0 |
| BA Assembly Mounting | • | • | • | • | • | 0 | 0 |
| BB Door Electronics Rear Driver Side | • | • | • | • | • | 0 | 0 |
| BC Door Electronics Rear Passenger Side | • | • | • | • | • | 0 | 0 |
| BD High Voltage Battery Charge Management | • | • | • | • | • | 0 | 0 |
| BE Sliding Door Rear Left | • | • | • | • | • | 0 | 0 |
| BF Sliding Door Rear Right | • | • | • | • | | 0 | 0 |
| CO Actuator For Exterior Noise | | | | • | | 0 | 0 |
| C1 Battery Regulation | | | | • | <u> </u> | 0 | 0 |
| C2 Transmission Control Module 2 | | • | | • | <u> </u> | 0 | 0 |
| | | | | | | + + | |
| C3 Drive Motor Control Module 3 | | | | • | | 0 | 0 |
| C4 DC/DC Converter Control Module | • | • | | • | | + + | |
| C5 Thermal Management | • | • | • | • | • | 0 | 0 |
| C6 Battery Charger Control Module | • | • | • | • | | 0 | 0 |
| C7 Pedestrian Protection | - | | • | • | | 0 | 0 |
| C8 Auxiliary Display Control Unit 2 | • | • | • | • | | 0 | 0 |
| C9 Rear Mirror | • | • | • | • | • | 0 | 0 |
| CA Control Module For Sunroof | • | • | • | • | • | 0 | 0 |
| CB Rear Axle Steering | • | • | • | • | • | 0 | 0 |
| CC Starter / Generator Control Module | • | • | • | • | • | 0 | 0 |
| CD Laser Scanner | • | • | • | • | • | 0 | 0 |
| CE Drive Motor Control Module 2 | • | • | • | • | • | 0 | 0 |
| CF Control Unit Lane Change Assistant 2 | • | • | • | • | • | 0 | 0 |
| DO Front Axle Lift System | • | • | • | • | • | 0 | 0 |
| D1 Center Display | • | • | • | • | • | 0 | 0 |
| D2 Sliding Door Left | • | • | • | • | • | 0 | 0 |
| D3 Sliding Door Right | • | • | • | • | • | 0 | 0 |

| D4 Roll Control System 1 | • | • | • | • | • | 0 | 0 |
|--|---|---|---|---|---|---|---|
| D5 Roll Control System 2 | • | • | • | • | • | 0 | 0 |
| D6 Light Control Left 2 | • | • | • | • | • | 0 | 0 |
| D7 Light Control Right 2 | • | • | • | • | • | 0 | 0 |
| D8 Projection Module in Left Matrix Headlamp | • | • | • | • | • | 0 | 0 |
| D9 Projection Module in Right Matrix | • | • | • | • | • | 0 | 0 |
| DB Front Corner Radar 1 | • | • | • | • | • | 0 | 0 |
| DC Front Corner Radar 2 | • | • | • | • | • | 0 | 0 |
| DD Control Module 2 For Sunroof | • | • | • | • | • | 0 | 0 |
| DE Charger 1 Mobile Devices | • | • | • | • | • | 0 | 0 |
| DF Charger 2 Mobile Devices | • | • | • | • | • | 0 | 0 |
| EO Auxiliary Display Control Unit 1 | • | • | • | • | • | 0 | 0 |
| EF Reference Control Unit | • | • | • | • | • | 0 | 0 |

SEAT OIL Function List(Note:For reference only)

NOTES:

- This function is supported. (Except that the electronic control unit not equipped)
- O This function is not supported.
- ▲ This function is the new feature in this version.

| Vehicle | Year | OIL |
|----------|-------------|-----|
| Alhambra | 2001 - 2019 | • |
| Altea | 2004 - 2015 | • |
| Arosa | 2001 - 2004 | • |
| Cordoba | 1999 - 2009 | • |
| Exeo | 2009 - 2014 | |
| Ibiza | 1999 - 2019 | • |
| Inca | 2001 - 2003 | • |
| Leon | 2000 - 2019 | • |
| Mii | 2012 - 2019 | • |
| Toledo | 1999 - 2010 | • |
| Toledo | 2013 - 2019 | • |

OIL Function List

Adapting Vehicle To Fixed Interval

Adapting Vehicle To Flexible Service Interval

iCarsoft

SEAT BMS Function List(Note:For reference only)

NOTES:

- This function is supported. (Except that the electronic control unit not equipped)
- * This function may be supported, which depends on the actual condition of the
- O This function is not supported.
- ▲ This function is the new feature in this version.

| Vehicle | Year | BMS |
|----------|-------------|-----|
| ALHAMBRA | 2001 - 2019 | • |
| Altea | 2004 - 2015 | • |
| Ateca | 2017 - 2019 | |
| Leon | 2000 - 2019 | |
| Mii | 2012 - 2019 | |
| Toledo | 1999 - 2010 | • |
| Toledo | 2013 - 2019 | • |

BMS Function List

Configure new battery parameter

| SEAT DPF Function List(Note:For reference only) | | | | | |
|---|---|--|--|--|--|
| NOTES: | | | | | |
| • This function is supported. (Ex | cept that the electronic control unit not equipped) | | | | |
| * This function may be supported | , which depends on the actual condition of the | | | | |
| O This function is not supported | • | | | | |
| ▲ This function is the new featu | re in this version. | | | | |
| Vehicle Year | DPF | | | | |
| LEON 2000 - 2019 | • | | | | |
| DPF Function List | | | | | |
| DPF Check | | | | | |
| DPF Matching | | | | | |
| DPF Regeneration | | | | | |

SEAT EPB Function List(Note:For reference only)

NOTES:

- This function is supported. (Except that the electronic control unit not equipped)
- * This function may be supported, which depends on the actual condition of the
- O This function is not supported.
- This function is the new feature in this version.

| Vehicle | Year | EPB |
|----------|-------------|-----|
| Alhambra | 2001 - 2019 | • |
| Altea | 2004 - 2015 | • |
| Ateca | 2017 - 2019 | • |
| Arosa | 2001 - 2004 | |
| Cordoba | 1999 - 2009 | • |
| Exeo | 2009 - 2014 | • |
| Ibiza | 1999 - 2019 | |
| Inca | 2001 - 2003 | |
| Leon | 2000 - 2019 | • |
| Mii | 2012 - 2019 | |
| Toledo | 1999 - 2010 | • |
| Toledo | 2013 - 2019 | • |

EPB Function List

Open Rear Brake Calipers(Ready to change brake pads) Close Rear Brake Calipers(After replacement of brake pads)

SEAT ETC Function List(Note:For reference only)

NOTES:

- This function is supported. (Except that the electronic control unit not equipped)
- O This function is not supported.
- lacktriangle This function is the new feature in this version.

| Vehicle | Year | ETC |
|----------|-------------|-----|
| Alhambra | 2001 - 2019 | • |
| Altea | 2004 - 2015 | • |
| Ateca | 2017 - 2019 | • |
| Arosa | 2001 - 2004 | |
| Cordoba | 1999 - 2009 | • |
| Exeo | 2009 - 2014 | • |
| Ibiza | 1999 - 2019 | |
| Inca | 2001 - 2003 | |
| Leon | 2000 - 2019 | • |
| Mii | 2012 - 2019 | |
| Toledo | 1999 - 2010 | • |
| Toledo | 2013 - 2019 | • |

ETC Function List

Electronic throttle sensor reset

| S | SEAT INJ Function List(Note:For reference only) | | | | | |
|-------------|---|---|--|--|--|--|
| NOTES: | NOTES: | | | | | |
| • This fun | ction is supported | d. (Except that the electronic control unit not equipped) | | | | |
| ₩ This fun | ction may be suppo | orted, which depends on the actual condition of the | | | | |
| O This fun | ction is not suppo | orted. | | | | |
| ▲ This fun | ction is the new | feature in this version. | | | | |
| Vehicle | Year | INJ | | | | |
| LEON | 2000 - 2019 | • | | | | |
| | INJ Function List | | | | | |
| Injector ma | Injector matching | | | | | |

SEAT SAS Function List (Note:For reference only)

NOTES:

- This function is supported. (Except that the electronic control unit not equipped)
- O This function is not supported.
- ▲ This function is the new feature in this version.

| Vehicle | Year | SAS |
|----------|-------------|-----|
| Alhambra | 2001 - 2019 | • |
| Altea | 2004 - 2015 | • |
| Arosa | 2001 - 2004 | • |
| Cordoba | 1999 - 2009 | • |
| Exeo | 2009 - 2014 | • |
| Ibiza | 1999 - 2019 | • |
| Inca | 2001 - 2003 | |
| Leon | 2000 - 2019 | • |
| Mii | 2012 - 2019 | |
| Toledo | 1999 - 2010 | • |
| Toledo | 2013 - 2019 | • |

SAS Function List

Steering Angle Learning

SEAT SPS Function List(Note:For reference only)

NOTES:

- This function is supported. (Except that the electronic control unit not equipped)
- O This function is not supported.
- ▲ This function is the new feature in this version.

| Vehicle | Year | SPS |
|----------|-------------|-----|
| Alhambra | 2001 - 2019 | * |
| Altea | 2004 - 2015 | * |
| Arosa | 2001 - 2004 | * |
| Cordoba | 1999 - 2009 | * |
| Exeo | 2009 - 2014 | * |
| Ibiza | 1999 - 2019 | * |
| Inca | 2001 - 2003 | * |
| Leon | 2000 - 2019 | * |
| Mii | 2012 - 2019 | * |
| Toledo | 1999 - 2010 | * |
| Toledo | 2013 - 2019 | * |

SPS Function List

Air Suspension Matching

SEAT LAP Function List(Note:For reference only)

NOTES:

- This function is supported. (Except that the electronic control unit not equipped)
- O This function is not supported.
- ▲ This function is the new feature in this version.

| Vehicle | Year | LAP |
|----------|-------------|-----|
| Alhambra | 2001 - 2019 | * |
| Altea | 2004 - 2015 | * |
| Arosa | 2001 - 2004 | * |
| Cordoba | 1999 - 2009 | * |
| Exeo | 2009 - 2014 | * |
| Ibiza | 1999 - 2019 | * |
| Inca | 2001 - 2003 | * |
| Leon | 2000 - 2019 | * |
| Mii | 2012 - 2019 | * |
| Toledo | 1999 - 2010 | * |
| Toledo | 2013 - 2019 | * |

LAP Function List

Headlamp Adjustment