

Question:

After finishing software update, it needs to be restarted to update to the tool, how to do if connection being cut off while MI6 is updating

Answer:

If this happens, the tool cannot start up anymore, you will need to restore the [load file]

Step 1:

Connect the MI6 tool with the PC by a USB cable, open [My Computer], then you will see a removable disk named [Removable Disk].

Step 2:

Double click the folder [Ultimate GD]. Then click the folder [UPDATA], then you will see the [load.bin] file.

Please copy the file to your desktop or another location.

Step3:

Disconnect and reconnect the tool with the PC again by a USB cable and press the shortcut key at the same time, the MI6 will be powered up and the light at up-right corner will be red and in quick blink, when you see this, please stop pressing the key

Step2:

Open the folder [My computer], you will see a removable disk named [CARE ENABLE], double click to enter the disk, you will see a file named [load file].

Step3:

Replace this [load file] with the one you have copied to your desktop

Step4:

After overwrite the file, close the removable disk and disconnect tool with PC

Step 5:

Connect tool with PC again (Note: do not press shortcut key this time), wait for few seconds, the tool will be powered up and will enter to start display automatically.